MODEL : BBT 61176 A2 (W1400 x L1900) BED

ASSEMBLY INSTRUCTIONS

1 OF 5

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY. Tool needed : Screwdriver (not provider).

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
Α	HEADBOARD	1 PC	1	JCBC BOLT M6 x 40mm and comments	22 PCS
В	HEADBOARD LEG	2 PCS	2	M6 FLAT WASHER	14 PCS
C	FOOTBOARD	1 PC	3	M6 SPRING WASHER	14 PCS
D	FOOTBOARD LEG	2 PCS	4	WOOD SCREW M3.5 x 16mm	8 PCS
E	SIDE RAIL	2 PCS	5	WOOD SCREW M4 x 20mm	2 PCS
F	SIDE RAIL SUPPORT WOOD	2 PCS			
G	CENTER RAIL	1 PC	6	WOOD DOWEL M8 x 30mm	12 PCS
Н	CENTER SUPPORT LEG	3 PCS	7	M4 ALLEN KEY (BALL SHAPE)	1 PC
Ι	CENTER SUPPORT	2 PCS	8	M5 ALLEN KEY (BALL SHAPE)	1 PC
J	BED SLAT	24 PCS	9	BED SLAT SIDE FITTER	24 PCS
			10	BED SLAT CENTER FITTER	12 PCS









