ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	HEADBOARD LEG	2 PCS	
С	FOOTBOARD	1 PC	
D	FOOTBOARD LEG	2 PCS	
E	SIDE RAIL	2 PCS	
F	SIDE RAIL SUPPORT WOOD	2 PCS	
G	CENTER RAIL	1 PC	
Н	CENTER SUPPORT LEG	3 PCS	
I	CENTER SUPPORT	2 PCS	
J	BED SLAT	26 PCS	

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 40mm	‱	22 PCS
2	M6 FLAT WASHER	0	14 PCS
3	M6 SPRING WASHER		14 PCS
4	WOOD SCREW M3.5 x 16mm	-mmmmx()	8 PCS
5	WOOD SCREW M4 x 20mm	<===== €	2 PCS
6	WOOD DOWEL M8 x 30mm		12 PCS
7	M4 ALLEN KEY (BALL SHAPE)		1 PC
8	M5 ALLEN KEY (BALL SHAPE)		1 PC
9	BED SLAT SIDE FITTER		26 PCS
10	BED SLAT CENTER FITTER	\Diamond	13 PCS

STEP 1









