ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	FOOTBOARD	1 PC	
C	FOOTBOARD LEG	2 PCS	
D	SIDE RAIL	2 PCS	
E	SIDE RAIL SUPPORT WOOD	2 PCS	
F	CENTER RAIL	1 PC	
G	CENTER SUPPORT LEG	3 PCS	
Н	CENTER SUPPORT	2 PCS	
I	BED SLAT	24 PCS	
J	BED LEG (1)	2 PCS	
K	BED LEG (2)	2 PCS	

HARDWARE LIST			
ITEM	DESCRIPTION	QTY	
1	JCBC BOLT M6 x 40mm	20 PCS	
2	M6 FLAT WASHER	8 PCS	
3	M6 SPRING WASHER	8 PCS	
4	WOOD SCREW M3.5 x 16mm	8 PCS	
5	WOOD DOWEL M8 x 30mm	8 PCS	
6	BED SLAT SIDE FITTER	24 PCS	
7	BED SLAT CENTER FITTER	12 PCS	
8	M4 ALLEN KEY (BALL SHAPE)	1 PC	
9	M5 ALLEN KEY (BALL SHAPE)	1 PC	









